

# SEGUE DESIGNS





## Using Your Setup Instructions DESIGNS The Visionary Designs Setup Instructions are created specifically for your

The Visionary Designs Setup Instructions are created specifically for your configuration. They are laid out sequentially, including an exploded view of the entire display, and then a logical series of detailed steps to assemble the main structure and components. We encourage you to study the instructions **before** attempting to assemble your exhibit.

Each page reminds you to tighten the setscrews after disassembling your exhibit to prevent loss of the locks and setscrews (see below in RED). This is VERY IMPORTANT.

Cleaning and Packing Your Display

1) Use care when cleaning aluminum extrusion or acrylic inserts. Use only


- 1) Use care when cleaning aluminum extrusion or acrylic inserts. Use only non-abrasive cleaners.
- 2) When cleaning laminate inserts or countertops, use mild cleansers and a soft material such as cotton.
- 3) Keep all display components away from extreme heat and long exposure to sunlight to avoid warping and fading.
- 4) Retain all packing material. It will make re-packing much easier and will reduce the likelihood of shipping damage.



Most Visionary Designs exhibits can be assembled with the supplied Hex Key Tool. Occasionally, a flat head screwdriver may be required.



Most horizontal extrusion connections have a patented expandable lock. This lock inserts into the groove of an opposing extrusion. Tightening the lock with the Hex Key Tool expands the lock and creates a strong positive connection.




Each extrusion contains a numbered label which corresponds with setup instructions.

The label is located within a groove of the extrusion


The label is located within a groove of the extrusion (when possible). With Visionary Designs the labels contain Black numbers unless otherwise specified.



Remove only (1) setscrew when disassembling. Replace setscrew in extrusion after assembling it. Before packing, replace setscrew in extrusion to avoid losing it.



Attach base plate to round or square vertical extrusion using the bolt provided. Be careful not to strip the threads.




When vertical extrusions are packed in portable cases rather than crates or tubs, they must broken down into smaller sections which then require assembly.

Remove only (2) setscrews when disassembling. Replace setscrews in extrusion after assembling it. Before packing, replace setscrews in extrusion to avoid losing them.




WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING

## **SEG Graphic: To Ensure Proper Fit**



It is important to first insert graphic into each alternater corner then to the sides of the frame.

If this is not done, graphic will not fit into the frame correctly.



Step 1
Insert corner A.
Turn edge of graphic so silicon welt is perpendicular to face of graphic.
Insert narrow side of welt with fabric to outside into the channel.
Repeat for other side of this corner.




Step 2
Repeat Step 1 for opposite corner
C, then insert corner B, followed by
corner corner D, to complete the
installation of the corners.




Step 3
Once all corners are inserted, press one silicon edge into channel from corners and work toward the center.
Make sure welt is fully inserted into channel. Continue until all sides are done. Smooth out edges of graphic.

## **Graphic Removal**



To remove the graphic from the frame, locate the fabric pull tab.

Gently pull up on the tab to remove the fabric.





© 2012

866.652.2100 Light Connection Attach Lights to Backwall where desired and tighten in place. A10 Clamp Attachment (If Removed) \* Literature Rack Attachment Slide connector on back of A10 clamp into groove of extrusion. When desired location is found, tighten set screw to secure. Tighten Lock to Secure Attach connector piece to rack as shown. Then connect assembled literature Tighten plastic knob rack to vertical extrusion. to secure wing in place.

WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING

866.652.2100

- 1) Connect canopy pieces together as shown.
- 2) Apply pillow case graphic to assembled canopy


### **Using Your Setup Instructions**

The Aero Overhead Sign Setup Instructions are created specifically for your configuration. They include an exploded view of the frame which is sequentially numbered. We encourage you to study the instructions before attempting to assemble your exhibit.


Connections are kept very simple: no tools. Everything assembles with push-button connectors and pre-connected horizontal sections.


#### **Cleaning and Packing Your Display**


- 1) Use care when cleaning aluminum extrusion or acrylic inserts. Use only non-abrasive cleaners.
- 2) Retain all packing material. It will make re-packing much easier and will reduce the likelihood of shipping damage.




Connections are made by holding the button down and sliding the red tube into opposing tube until the connection is made. To disassemble push button and pull or twist extrusions apart.







Steps:



WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING


866.652.2100


### Setup Instructions:

A) Use standoff screws to secure the front panel with door and back panel of the pedestal to the side panels.


Floor


B) After assembling front, back, and side panels, slide floor into the bottom of the pedestal. The























Top View

